SNS: Analytic Receiver Analysis Software Using Electrical Scattering Matrices

Oliver G. King^{*†}

*California Institute of Technology, MC 249-17, 1200 E. California Blvd., Pasadena, CA, 91125 [†]Contact: ogk@astro.caltech.edu

Abstract—SNS is a MATLAB-based software library written to aid in the design and analysis of receiver architectures. It uses electrical scattering matrices and noise wave vectors to describe receiver architectures of arbitrary topology and complexity. It differs from existing freely-available software mainly in that the scattering matrices used to describe the receiver and its components are analytic rather than numeric. This allows different types of modeling and analysis of receivers to be performed.

Non-ideal behavior of receiver components can be parameterized in their scattering matrices. SNS enables the instrument designer to then derive analytic expressions for the signal and noise at the receiver outputs in terms of parameterized component imperfections, and predict their contribution to receiver systematic errors precisely. This can drive the receiver design process by, for instance, allowing the instrument designer to identify which component imperfections contribute most to receiver systematic errors, and hence place firm specifications on individual components. Using SNS to perform this analysis is preferable to traditional Jones matrix-based analysis as it includes internal reflections and is able to model noise: two effects which Jones matrix analysis is unable to describe.

SNS can be used to model any receiver in which the components can be described by scattering matrices. Of particular interest to the sub-mm and terahertz frequency regime is the choice between coherent and direct detection technologies. Steady improvements in mm and sub-mm Low Noise Amplifiers (LNAs) mean that coherent receivers with LNAs as their first active element are becoming increasingly competitive, in terms of sensitivity, with bolometer-based receivers at frequencies above $\sim 100~{\rm GHz}.$

As an example of the utility of SNS, we use it to compare two polarimeter architectures commonly used to perform measurements of the polarized Cosmic Microwave Background: differencing polarimeters, an architecture commonly used in polarization sensitive bolometer-based polarimeters; and pseudocorrelation polarimeters, an architecture commonly used in coherent, LNA-based, polarimeters. We parameterize common sources of receiver systematic errors in both architectures and compare them through their Mueller matrices, which encode how well the instruments measure the Stokes parameters of the incident radiation. These analytic Mueller matrices are used to demonstrate the different sources of systematic errors in differencing and correlation polarimeters.

I. INTRODUCTION

Many fields of astrophysics aim to measure increasingly faint signals. For instance, there is great interest at present in detecting and characterizing the B-mode [1] of the polarized Cosmic Microwave Background (CMB). The strength of this signal is not yet determined by theory, but a strong upper limit is 170 nK [2], a tiny fraction of the CMB total intensity signal (~ 2.7 K).

An instrument built to detect very faint signals will almost certainly be heavily affected by systematic errors. It is increasingly important to be able to model the effects of receiver systematic errors on the measured signal, and on the receiver sensitivity. We want to be able predict the level of receiver systematic errors, show their impact on the gathered data, and make quantitative comparisons between different receiver architectures.

Previous analytic and semi-analytic approaches to characterizing systematic effects in receivers have usually employed Jones matrices to describe receiver components and Mueller matrices to characterize the effects of receiver systematics on the observed Stokes parameters [3], [4]. The use of Jones matrices to describe individual receiver components has several shortcomings. Only the forward path of the signal through the instrument is modeled – internal scattering caused by reflections from poorly matched components is not included; and Jones matrix modeling is unable to describe component noise, and hence receiver sensitivity. Modeling a receiver with a full analytic description of the outputs and sensitivity in terms of individual component parameters allows us to identify which parameters of each component in a receiver are most important, and concentrate our efforts on improving them.

This paper introduces a technique and software for developing full analytic descriptions of receiver outputs and sensitivities in terms of lab-measureable errors in individual components. In this technique components are modeled by electrical scattering matrices. When describing a network of components with Jones matrices the forward-path cascaded response can be obtained through simple matrix manipulation and multiplication. The scattering matrix formulation does not share this simplicity of calculation: only the case of cascaded 2-port devices is amenable to a relatively simple analytic solution. This paper describes an algorithm for calculating the response of arbitrarily connected networks of components. We present software which implements this algorithm, and apply it to two common polarimeter architectures: differencing polarimeters, and pseudo-correlation polarimeters.

This software allows us to make robust analytic comparisons of receiver architectures. Errors in individual receiver components can be parameterized and propagated into the description of the receiver performance, e.g. the instrument Mueller matrix. We hence have a powerful tool for guiding the instrument design process and diagnosing the causes of non-ideal instrument behavior.

II. ELECTRICAL SCATTERING MATRICES

We model the behavior of individual receiver components, and the full receiver, using electrical scattering matrices. The electrical scattering matrix (hereafter referred to as the scattering matrix) is a representation of a network using the ideas of incident, reflected, and transmitted waves. It provides a complete description of an N-port network as seen at its N ports. A significant advantage of modeling receiver components with scattering matrices is that *noise* can easily be included in the modeling. The noise produced by a device is modeled with a noise wave vector; see e.g. [5].

Consider the arbitrary N-port network shown in Figure 1a. We denote the incident wave at port i by V_i^+ , the reflected wave by V_i^- , and the noise wave produced by the network at that port by c_i . These quantities are related by the scattering matrix **S** and noise wave vector **c** as follows:

$$\begin{bmatrix} V_1^- \\ V_2^- \\ \vdots \\ V_N^- \end{bmatrix} = \begin{bmatrix} S_{11} & S_{12} & \cdots & S_{1N} \\ S_{21} & & \vdots \\ \vdots & & & \\ S_{N1} & \cdots & S_{NN} \end{bmatrix} \begin{bmatrix} V_1^+ \\ V_2^+ \\ \vdots \\ V_N^+ \end{bmatrix} + \begin{bmatrix} c_1 \\ c_2 \\ \vdots \\ c_N \end{bmatrix}$$
(1)

The noise wave voltages c_i of an N-port network are complex time-varying random variables characterized by a correlation matrix C

$$\mathbf{C} = \langle \mathbf{c} \otimes \mathbf{c}^{\dagger} \rangle$$
$$= \begin{bmatrix} \langle |c_1|^2 \rangle & \langle c_1 c_2^* \rangle & \cdots & \langle c_1 c_N^* \rangle \\ \langle c_2 c_1^* \rangle & & \vdots \\ \vdots & & \\ \langle c_N c_1^* \rangle & \cdots & \langle |c_N|^2 \rangle \end{bmatrix}$$

where the angle brackets indicate time averaging, \dagger indicates the conjugate transpose operation, and \otimes indicates the outer product (or Kronecker product). The diagonal terms of C give the noise power deliverable at each port in a 1 Hz bandwidth. The off-diagonal terms are correlation products. The noise correlation matrix C for a passive network is determined from its scattering matrix S by [6]

$$\mathbf{C} = kT(\mathbf{I} - \mathbf{SS}^{\dagger}) \tag{2}$$

where k is Boltzmann's constant, T is the physical temperature of the network, and I is the identity matrix. The noise correlation matrix for an active network can be determined by measurement or modeling.

III. SOLVING ARBITRARY NETWORKS

Consider the arbitrarily connected network of N-port networks shown in Figure 1b. We need an algorithm to calculate the scattering matrix **S** and noise wave vector **c** which describe the connected network. The algorithm derived here is an extension of the algorithm described in [7], with added noise wave vector manipulation. Similar algorithms are used numerically in SUPERMIX [8].

First, let us consider the effect of connecting together ports k and m of an N-port network described by Equation 1. Connecting the ports means that $V_k^+ = V_m^-$ and $V_k^- = V_m^+$. Manipulation of rows k and m of Equation 1 then gives us the expressions

$$V_m^- = \sum_{i \neq k,m} \frac{S_{mi}}{1 - S_{mk}} V_i^+ + \frac{S_{mm}}{1 - S_{mk}} V_k^- + \frac{c_m}{1 - S_{mk}} \quad (3)$$

$$V_k^- = \sum_{i \neq k,m} \frac{S_{ki}}{1 - S_{km}} V_i^+ + \frac{S_{kk}}{1 - S_{km}} V_m^- + \frac{c_k}{1 - S_{km}} \quad (4)$$

By substituting Equations 3 and 4 into each other we can obtain expressions for V_m^- and V_k^- . Substituting these expressions into Equation 1 we can obtain a new expression for the reflected wave V_i^- :

$$V_{i}^{-} = \sum_{j \neq k,m} \left[S_{ij} + \frac{(1 - S_{km})(1 - S_{mk})}{(1 - S_{km})(1 - S_{mk}) - S_{kk}S_{mm}} \\ \left(\frac{S_{ik}S_{mj}}{1 - S_{mk}} + \frac{S_{ik}S_{mm}S_{kj}}{(1 - S_{mk})(1 - S_{km})} \\ + \frac{S_{im}S_{kj}}{1 - S_{km}} + \frac{S_{im}S_{kk}S_{mj}}{(1 - S_{km})(1 - S_{mk})} \right) \right] V_{j}^{+} \\ + c_{i} + S_{ik} \left(\frac{(1 - S_{km})c_{m} + S_{mm}c_{k}}{(1 - S_{km})(1 - S_{mk}) - S_{kk}S_{mm}} \right) \\ + S_{im} \left(\frac{(1 - S_{mk})c_{k} + S_{kk}c_{m}}{(1 - S_{km})(1 - S_{mk}) - S_{kk}S_{mm}} \right)$$
(5)

From Equation 5 we obtain replacement expressions for the elements S_{ij} of **S** and the noise waves c_i :

$$S_{ij}^{\text{new}} = S_{ij} + A \Big[S_{ik} S_{mj} (1 - S_{km}) + S_{ik} S_{kj} S_{mm} \\ + S_{im} S_{kj} (1 - S_{mk}) + S_{im} S_{mj} S_{kk} \Big]$$
(6)
$$c_i^{\text{new}} = c_i + A \Big[\Big(S_{im} S_{kk} + S_{ik} (1 - S_{km}) \Big) c_m \\ + \Big(S_{ik} S_{mm} + S_{im} (1 - S_{mk}) \Big) c_k \Big]$$
(7)

where $A = \frac{1}{(1 - S_{km})(1 - S_{mk}) - S_{kk}S_{mm}}$

Rows and columns k and m are then removed from **S** and rows k and m are removed from **c** to create the scattering matrix and noise vector which describe the new (N-2)-port network.

A. Algorithm

To obtain the scattering matrix and noise wave vector which describe the arbitrarily connected network shown in Figure 1b begin by forming the scattering matrix and noise wave vector which describe the unconnected network:

$$\mathbf{S} = \begin{bmatrix} \mathbf{S}_1 & \mathbf{0} & \cdots & \mathbf{0} \\ \mathbf{0} & \mathbf{S}_2 & & \vdots \\ \vdots & & & \\ \mathbf{0} & \cdots & \mathbf{S}_N \end{bmatrix}, \mathbf{c} = \begin{bmatrix} \mathbf{c}_1 \\ \mathbf{c}_2 \\ \vdots \\ \mathbf{c}_N \end{bmatrix}$$
(8)



Fig. 1. (a) An arbitrary N-port network. The total signal at each port p_i consists of an incident signal V_i^+ , a reflected signal V_i^- , and a noise signal c_i . The reflected signal V_i^- is a weighted sum of the incident signal at port *i* and transmitted signals from the other ports of the network, the coefficients of the sum being the elements of the network scattering matrix S. The noise signals are given by the noise wave vector c. (b) An arbitrarily connected network of N-port devices.

We then successively form each connection in the network. For each connection, find the rows and columns k and m of S and c in Equation 8 which correspond to the ports being connected. Use the replacement formulae given by Equations 6 and 7 to adjust the S matrix and c vector. Remove rows and columns k and m from S, and rows k and m from c. Repeat for each remaining connection until we are left with the scattering matrix S and noise vector c which describe the fully connected network.

IV. SOFTWARE IMPLEMENTATION

We have derived an algorithm in §III-A for finding the scattering matrix and noise wave vector which describe an arbitrarily connected network. We need to be able to apply it to arbitrary receivers with parameterized scattering matrices describing the receiver components and obtain analytic expressions for the outputs and noise in terms of the component parameters.

The algorithm must be implemented in a programming language with the ability to manipulate symbolic algebraic



3



Fig. 2. Schematic showing the nature of node and N-port objects and how they connect to each other in the software.

expressions. This programming language must also support pointers (or equivalent data structure) to allow the creation of a navigateable network. We implemented the algorithm in MATLAB¹, which has a powerful and well developed symbolic algebra toolbox. While it does not have a native pointer data type (as of version R2008b), a third party open-source pointer library² adds this capability. The software package we developed to perform this modeling is called SNS³.

A. Representing a Network

A network is represented by nodes and N-port objects, as shown in Figure 2. They are both pointer objects. Each N-port object contains an array of references to the nodes connected to each of its N ports, a scattering matrix S, a noise wave vector \mathbf{c} , and a variable N, the number of ports of the object.

Each node object contains two pointers; these refer to the N-port objects the node connects to in the "forward" and "backward" directions, and which port number the connection is made to $(N_{fp} \text{ and } N_{bp} \text{ respectively})$. Note that the forward and backward directions are completely arbitrary; they are merely a helpful concept when trying to visualize the operation of the algorithms which act on the network.

The network is constructed by creating all the node and N-port objects using functions called makeNode() and makeNport(), assigning scattering matrices and noise wave vectors to the N-port objects, and connecting each node to its forward and backward N-port objects. A connectNode function hides the complexity of assigning references to the appropriate array locations and assigning the appropriate port numbers to variables.

Nodes are classified into four types: input, output, central, and terminated. We want to calculate the performance of a network in terms of the response seen at the outputs due to signals presented at the inputs. The central and terminated nodes are removed by the network-solving program.

Once all the objects have been created, assigned matrices and vectors, and connected, it suffices to describe the network by the four arrays of nodes. Due to the fully connected nature of the network representation it is possible to start at any node and navigate to any other node by following the appropriate links between objects.

¹http://www.mathworks.com/

²http://code.google.com/p/pointer/

³Download at http://www.astro.caltech.edu/~ogk/SNS/

B. Solving a Network

The network-solving program accepts four arrays of nodes: the inputs, outputs, central nodes, and terminated nodes. It returns the scattering matrix and noise wave vector for the connected network, where the central and terminated nodes have been removed through application of the algorithm described in §III-A.

The first step the software performs is to remove the terminated nodes, if there are any. The software assumes that the terminations are perfectly matched and at a common physical temperature. It modifies the object scattering matrices to remove the terminated nodes, and adds the noise terms produced by the terminated nodes to the noise wave vectors.

The network *sans* terminated nodes is then passed to a recursive network shrinking program. This program begins with the first central node and applies the algorithm given by Equations 6 and 7 to a sub-network consisting of the two N-port objects connected to that particular node. A new N-port object is created and assigned the resulting scattering matrix and noise wave vector. All the nodes which were connected to the now-defunct N-port objects are reconnected to this new N-port object at the appropriate ports. A new network is formed by excluding the central node just considered and the program is recursively called on this new network. This continues until there are no more central nodes, at which point the scattering matrix and noise wave vector of the single remaining N-port object are returned.

Applying the algorithm in this fashion, rather than to the entire network at once, means that the size of the matrix S in Equation 8 is kept small, speeding up computation. This is not an optimum solution to network shrinking, but we have found it to be significantly faster than applying the algorithm to the full unconnected network for networks of more than a few N-port objects.

The description given above glosses over the significant complexity in keeping track of which nodes should be connected where, and certain configurations of nodes and N-port objects which would cause the default implementation of the algorithm to fail. The majority of the code is dedicated to performing these functions; only a small fraction of the code actually carries out the calculations described by the algorithm.

C. Example Code Listing

To illustrate the operation of the program consider the network shown in Figure 3. It is represented in software by connected lists of nodes and *N*-port objects, as shown in the following code listing:

% Matrices S1, S2, S3, S4, S5 and vectors c1, c2, c3, c4, c5 assumed to % have been previously defined using symbolic algebra library. % Make the N-port objects P1 = makeNport(); P2 = makeNport(); P4 = makeNport(); P5 = makeNport(); P4 = makeNport(); P5 = makeNport(); P4 = makeNport(); P5 = makeNport(); P1 = c1; P2.c = c2; P3.c = c3; P4.c = c4; P5.c = c5; % Make the nodes which connect the N-port objects In1 = makeNode(); In2 = makeNode(); On1 = makeNode(); On2 = makeNode(); Cn3 = makeNode(); Cn4 = makeNode(); Cn4 = makeNode(); Cn5 = makeNode(); % ConnectNode(In1,[],1,P1,1]); connectNode(In2,[],1,P1,4); connectNode(Cn3,P3,2,P5,1); connectNode(Cn4,P4,2,P2,4); connectNode(Cn5,P3,2,P5,1); connectNode(Cn4,P4,2,P2,1); connectNode(Cn5,P5,2,[],1); connectNode(On2,P2,2,[],1); % Build arrays of nodes inputs = [In1 In2]; outputs = [On1 On2];



Fig. 3. An arbitrary network of N-port devices to illustrate the software. Nodes are indicated by open circles, N-port devices by rectangles. N-port device *i* is described by scattering matrix S_i and noise wave vector c_i . Input nodes to the network are In_i , central nodes Cn_i , terminated nodes Tn_i , and output nodes On_i .

cnodes = {Cnl Cn2 Cn3 Cn4 Cn5}; tnodes = {Tnl}; % Pass arrays of nodes to network calculator [5, c] = getScatteringRecursive(inputs, outputs, cnodes, tnodes);

The getScatteringRecursive program performs the actions described in \S IV-B, and returns the scattering matrix S and noise wave vector c for the resulting 4-port object. Nodes In₁, In₂, On₁, and On₂ are connected sequentially to ports 1 to 4 of this object.

V. POLARIMETRY

The example presented in the coming section, §VI, compares two receiver architectures commonly used to measure linear polarization at radio to sub-mm wavelengths. This section provides necessary background information by sketching a brief summary of polarization. It shows how a receiver may be described by a Mueller matrix, and shows how to derive a receiver Mueller matrix from the scattering matrix produced by the software described in §IV.

A. Brief Summary of Polarization

An electromagnetic signal is said to be polarized if there is some lasting amplitude or phase relation between its orthogonal modes. The coherency vector [9] captures this relation:

$$\mathbf{e} = \left\langle \begin{bmatrix} E_x(t)E_x^*(t) \\ E_x(t)E_y^*(t) \\ E_y(t)E_x^*(t) \\ E_y(t)E_y^*(t) \end{bmatrix} \right\rangle$$
$$= \left\langle \mathbf{E} \otimes \mathbf{E}^* \right\rangle$$

Here **E** is the complex vector of the orthogonal modes $E_x(t)$ and $E_y(t)$ of the signal, $\langle \ldots \rangle$ indicates time averaging, and \otimes indicates the outer product.

If the signal **E** is acted on by an object described by a Jones matrix **J**, i.e. $\mathbf{E}_{out} = \mathbf{J}\mathbf{E}$, then the new coherency vector is given by

$$\mathbf{e}_{out} = (\mathbf{J} \otimes \mathbf{J}^*)\mathbf{e} \tag{9}$$

The polarization state of a signal is usually described by the Stokes parameters, I, Q, U, and V. I describes the total intensity of the signal, Q and U describe the linear polarization state, and V describes the circular polarization state. The Stokes vector e^S is obtained from the coherency vector e by

$$\mathbf{e}^{S} = \begin{bmatrix} I \\ Q \\ U \\ V \end{bmatrix} = \mathbf{T}\mathbf{e} \tag{10}$$

where
$$\mathbf{T} = \begin{bmatrix} 1 & 0 & 0 & 1 \\ 1 & 0 & 0 & -1 \\ 0 & 1 & 1 & 0 \\ 0 & -i & i & 0 \end{bmatrix}$$
 (11)

We see that \mathbf{T} is a coordinate transformation of the coherency vector to the abstract Stokes frame.

The Stokes parameters are a convenient and powerful way of the describing the state of polarization of an electromagnetic signal. From Equation 10 we have:

$$I = \langle |E_x(t)|^2 \rangle + \langle |E_y(t)|^2 \rangle$$

$$Q = \langle |E_x(t)|^2 \rangle - \langle |E_y(t)|^2 \rangle$$

$$U = 2 \langle \Re\{E_x(t)E_y^*(t)\} \rangle$$

$$= \langle E_x(t)E_y^*(t)\rangle + \langle E_x^*(t)E_y(t)\rangle$$

$$V = 2 \langle \Im\{E_x(t)E_y^*(t)\} \rangle$$

$$= -i[\langle E_x(t)E_y^*(t)\rangle - \langle E_x^*(t)E_y(t)\rangle]$$
(12)

a) Mueller Calculus: Suppose that a signal defined by the complex electric field vector \mathbf{E} and coherency vector \mathbf{e} is modified by an object described by the Jones matrix \mathbf{J} . From Equations 9 and 10 we see that the output signal $\mathbf{E}_{out} = \mathbf{J}\mathbf{E}$ will be described by the Stokes vector

$$\mathbf{e}_{out}^{S} = \mathbf{T}(\mathbf{J} \otimes \mathbf{J}^{*})\mathbf{T}^{-1}\mathbf{e}^{S}$$
$$= \mathbf{M}\mathbf{e}^{S}$$

The matrix $\mathbf{M} = \mathbf{T}(\mathbf{J} \otimes \mathbf{J}^*)\mathbf{T}^{-1}$ is called the Mueller matrix. It represents the action of the object characterized by Jones matrix \mathbf{J} in the Stokes vector space.

Mueller calculus is a matrix method for manipulating Stokes vectors. We denote the Mueller matrix elements as

$$\mathbf{M} = \begin{bmatrix} M_{II} & M_{IQ} & M_{IU} & M_{IV} \\ M_{QI} & M_{QQ} & M_{QU} & M_{QV} \\ M_{UI} & M_{UQ} & M_{UU} & M_{UV} \\ M_{VI} & M_{VQ} & M_{VU} & M_{VV} \end{bmatrix}$$

Mueller matrices are a convenient means of describing the action of an astronomical polarimeter. Of particular interest are the M_{QI} and M_{UI} parameters, which describe the leakage of the total intensity I into the measured linear polarization vector components. Much of the radio and mm/sub-mm spectrum is only slightly linearly polarized, hence non-zero values of M_{QI} and M_{UI} can imply serious contamination of the measured linear polarization vector by the total intensity signal.

B. Deriving Receiver Mueller Matrix

Say we have calculated the scattering matrix which describes the behavior of a receiver. For polarimeters, a natural way of expressing the receiver's performance is with a Mueller matrix. We need to translate the receiver scattering matrix into



Fig. 4. A arbitrary receiver, where orthogonal linear polarizations $E_x(t)$ and $E_y(t)$ are presented at inputs 1 and 2 respectively. D is the output at port m. The receiver is described by scattering matrix **S**.

a Mueller matrix which describes the action of the receiver on the Stokes vector of the incident electromagnetic signal.

Consider the arbitrary receiver shown in Figure 4. Orthogonal linear polarizations $E_x(t)$ and $E_y(t)$, representing either signals in transmission lines, orthogonal modes in waveguide, or orthogonal modes in free-space, are connected to ports 1 and 2 of the receiver respectively. Receiver output Dis connected to port m. The receiver is described by the scattering matrix S.

The output $E_m(t)$ seen at port m is given by (assuming that the connections to ports 3 to N are reflectionless):

$$E_m(t) = S_{m1}E_x(t) + S_{m2}E_y(t)$$

The power contained in the signal $E_m(t)$ is then measured. At radio wavelengths this is often achieved through the use of a square-law detector diode. At mm and sub-mm wavelengths a bolometer might be used. The measured power P_D is given by:

$$P_{D} = \alpha \langle E_{m}(t)E_{m}(t)^{*} \rangle$$

$$= \alpha \Big[\langle |E_{x}(t)|^{2} \rangle |S_{m1}|^{2} + \langle |E_{y}(t)|^{2} \rangle |S_{m2}|^{2}$$

$$+ \langle E_{x}(t)E_{y}^{*}(t) \rangle S_{m1}S_{m2}^{*}$$

$$+ \langle E_{x}^{*}(t)E_{y}(t) \rangle S_{m1}^{*}S_{m2} \Big]$$
(13)

where $\langle \ldots \rangle$ indicates time averaging, α is a proportionality constant dependent on the power detection method, and we assume that the instrument scattering matrix parameters are constant during the average time period. Now let

$$P_{D} = M_{DI}I + M_{DQ}Q + M_{DU}U + M_{DV}V$$

= $M_{DI}\langle |E_{x}(t)|^{2} + |E_{y}(t)|^{2}\rangle$
+ $M_{DQ}\langle |E_{x}(t)|^{2} - |E_{y}(t)|^{2}\rangle$
+ $M_{DU}\langle E_{x}(t)E_{y}^{*}(t) + E_{x}^{*}(t)E_{y}(t)\rangle$
- $iM_{DV}\langle E_{x}(t)E_{y}^{*}(t) - E_{x}^{*}(t)E_{y}(t)\rangle$ (14)

where we have used the definition of the Stokes parameters given in Equation 12.

By comparing Equations 13 and 14 we can obtain the contribution of each Stokes parameter to the power measured

at output D:

$$M_{DI} = \frac{\alpha}{2} \{ |S_{m1}|^2 + |S_{m2}|^2 \}$$

$$M_{DQ} = \frac{\alpha}{2} \{ |S_{m1}|^2 - |S_{m2}|^2 \}$$

$$M_{DU} = \frac{\alpha}{2} \{ S_{m1} S_{m2}^* + S_{m1}^* S_{m2} \}$$

$$M_{DV} = \frac{i\alpha}{2} \{ S_{m1} S_{m2}^* - S_{m1}^* S_{m2} \}$$
(15)

We can derive the receiver Mueller matrix by applying this technique to all the outputs of the receiver.

VI. POLARIMETER ARCHITECTURE COMPARISON

Two basic types of architectures are used to measure the polarization of an electromagnetic signal: differencing polarimeters, an architecture commonly used in polarization sensitive bolometer-based polarimeters [10]; and pseudo-correlation (or correlation) polarimeters, an architecture commonly used in coherent, LNA or mixer based, polarimeters such as QUIET [11].

Differencing polarimeters measure the difference in power between orthogonal linear modes of the electromagnetic signal; see the definition of Q in Equation 12 for inspiration. Correlation, or pseudo-correlation, architectures measure the polarization state by measuring the correlation between orthogonal modes. Correlation polarimeters are required to preserve the phase of the incident signal. They are hence only feasible if coherent (i.e. phase-preserving) amplifiers or mixers are available.

The choice of which architecture to use for a particular experiment is often dominated by sensitivity considerations. At low frequencies ($<\sim 60$ GHz) the availability of low-noise coherent amplifiers has favored correlation architectures [12]. At higher frequencies, the fundamental quantum limits that amplifier noise is subject to has favored direct detection technologies such as bolometers, and hence differencing polarimeter architectures, for continuum polarimetry experiments. However, continuing improvement in coherent amplifier technology at high frequencies has pushed their performance closer to the quantum limit, e.g. [13]. As coherent amplifier technology improves, sensitivity may no longer be the deciding factor between technologies, and hence architectures.

Differencing and correlation architectures measure the polarization information of the incident signal in very different ways, and hence suffer from different sources of systematic error. A careful analysis of the fundamental strengths and weaknesses of each architecture is needed. SNS is well suited to perform this analysis. In this section we use SNS to derive receiver Mueller matrices for examples of these two polarimeter architectures. This analysis highlights the different sources of systematic error in these architectures.

A. Differencing Polarimeters

An example of a differencing polarimeter architecture is shown in Figure 5 (right). The powers in orthogonal linear modes D_1 and D_2 are detected and differenced to obtain one of the linear polarization parameters. Differencing polarimeters have a much simpler architecture than pseudo-correlation



Fig. 5. Examples of two commonly used polarimeter architectures. (left) A pseudo-correlation polarimeter. (right) A differencing polarimeter. Orthogonal waveguide modes E_x and E_y are circularized or rotated, and extracted from waveguide by an orthomode transducer (OMT). In the pseudo-correlation architecture the signals are further processed. The powers in signals D_1 to D_4 are detected and processed to obtain the Stokes parameters, as explained in the text.

polarimeters. However, they measure only a single linear Stokes parameter; a duplicate receiver oriented at 45° to the first is needed to measure the second linear Stokes parameter.

B. Pseudo-correlation Polarimeters

An example of a pseudo-correlation polarimeter architecture is shown in Figure 5 (left). The Stokes parameters of linear polarization in a circular basis are given by:

$$E_{l}(t) = \frac{1}{\sqrt{2}} [E_{x}(t) - iE_{y}(t)]$$

$$E_{r}(t) = \frac{1}{\sqrt{2}} [E_{x}(t) + iE_{y}(t)]$$

$$Q = 2\langle \Re\{E_{l}(t)E_{r}^{*}(t)\}\rangle$$

$$U = -2\langle \Im\{E_{l}(t)E_{r}^{*}(t)\}\rangle$$
(16)

Pseudo-correlation polarimeters measure the linear Stokes vector by correlating circular polarization signals E_l and E_r with $(D_3 \text{ and } D_4)$ and without $(D_1 \text{ and } D_2)$ a 90° phase shift.

While the architecture of a pseudo-correlation polarimeter is more complex than that of a differencing polarimeter, it does provide some significant advantages. For instance, both linear polarization parameters can be measured with a single optical assembly, providing twice the information for the same focal plane area occupied.

C. Parameterized Scattering Matrices

Some of the components in the receivers shown in Figure 5 have parameterized scattering matrices. While it is possible to describe every component in a receiver with a suitable parameterized scattering matrix, the resulting analytic expressions for the outputs soon become too complicated to be useful when written down.

In this analysis the components are assumed to be perfectly matched, i.e. the diagonal elements of the parameterized scattering matrices are zero.

1) Circularizer: The circular phase shifter translates orthogonal linear polarizations into orthogonal circular polarizations. It introduces a 90° phase shift into one orthogonal linear mode, and is oriented at 45° to the OMT linear axis.

A possible parameterization of the circularizer's scattering matrix as shown in Figure 5 is:

$$\mathbf{S}_{circ} = \frac{L_c}{\sqrt{2}} \begin{bmatrix} 0 & 1 & 1 & 0\\ 1 & 0 & 0 & -e^{i(\frac{\pi}{2} + \theta_c)} \\ 1 & 0 & 0 & e^{i(\frac{\pi}{2} + \theta_c)} \\ 0 & -e^{i(\frac{\pi}{2} + \theta_c)} & e^{i(\frac{\pi}{2} + \theta_c)} & 0 \end{bmatrix}$$

Here L_c^2 is the insertion loss of the circularizer, and θ_c is the error in the 90° phase shift. The circularizer is assumed to be otherwise perfect.

2) Faraday Rotator: The Faraday rotator shown in the differencing polarimeter in Figure 5 is a component sometimes used in PSBs [14]. It modulates the measured polarization signal by introducing a variable rotation to the plane of linear polarization of the incident signal. A similar effect can be achieved with a rotating birefringent half-waveplate, or a wire grid.

The scattering matrix for the rotator considered here is:

$$\mathbf{S}_{fr} = \begin{bmatrix} 0 & \cos(\theta_{ps}) & \sin(\theta_{ps}) & 0\\ \cos(\theta_{ps}) & 0 & 0 & -\sin(\theta_{ps})\\ \sin(\theta_{ps}) & 0 & 0 & \cos(\theta_{ps})\\ 0 & -\sin(\theta_{ps}) & \cos(\theta_{ps}) & 0 \end{bmatrix}$$

Here $2\theta_{ps}$ is the time-dependent linear plane rotation introduced by the Faraday rotator.

3) OMT: The OMT extracts orthogonal linear modes from the waveguide. The scattering matrix parameterization considered here is:

$$\mathbf{S}_{OMT} = \begin{bmatrix} 0 & D_x & d_{yx} & 0 \\ D_x & 0 & 0 & d_{xy} \\ d_{yx} & 0 & 0 & D_y \\ 0 & d_{xy} & D_y & 0 \end{bmatrix}$$

Here D_x and D_y measure the insertion loss for each orthogonal mode, while d_{xy} and d_{yx} measure the leakage of one mode

4) LNAs and Phase Switch: The scattering matrices for the LNAs in the pseudo-correlation polarimeter are given by:

$$\mathbf{S}_{L,R} = \begin{bmatrix} 0 & 0\\ G_{L,R} & 0 \end{bmatrix}$$

Here G_L and G_R are the complex voltage gains of the left and right circular polarization amplifiers respectively.

The phase switch in the pseudo-correlation polarimeter modulates the phase of one of the signal arms relative to the other. Its scattering matrix is given by:

$$\mathbf{S}_{ps} = \begin{bmatrix} 0 & e^{i\theta_{ps}} \\ e^{i\theta_{ps}} & 0 \end{bmatrix}$$

Here θ_{ps} is the time-dependent phase shift introduced by the phase switch, usually shifting between 0° and 180° .

D. Polarimeter Mueller Matrix Elements

We now build a connected model of each polarimeter in SNS using the matrix parameterizations given in \S VI-C. We use Equation 15 to obtain expressions for the powers measured at each receiver output in terms of the incident signal Stokes parameters.

For the ideal pseudo-correlation polarimeter, i.e. where all the components are perfect, the outputs are:

$$P_{D_{1}} = \frac{1}{2}I - \frac{1}{2}U$$

$$P_{D_{2}} = \frac{1}{2}I + \frac{1}{2}U$$

$$P_{D_{3}} = \frac{1}{2}I - \frac{1}{2}Q$$

$$P_{D_{4}} = \frac{1}{2}I + \frac{1}{2}Q$$
(17)

Here we have assumed that $\theta_{ps} = 0$ and $\alpha = 1$. To measure the Stokes parameters we take $Q_m = P_{D_4} - P_{D_3}, U_m =$ $P_{D_2} - P_{D_1}$, and $I_m = \frac{1}{2}(P_{D_1} + P_{D_2} + P_{D_3} + P_{D_4})$.

For the ideal differencing polarimeter the outputs are:

$$P_{D_1} = \frac{1}{2}I + \frac{1}{2}\cos(2\theta_{ps})Q - \frac{1}{2}\sin(2\theta_{ps})U$$
$$P_{D_2} = \frac{1}{2}I - \frac{1}{2}\cos(2\theta_{ps})Q + \frac{1}{2}\sin(2\theta_{ps})U$$
(18)

Which linear Stokes parameter we measure depends on the plane rotation introduced by the Faraday rotator, and is given by $L_m = P_{D_1} - P_{D_2} = \cos(2\theta_{ps})Q - \sin(2\theta_{ps})U$. The measured total intensity is $I_m = P_{D_1} + P_{D_2}$.

The Mueller matrix parameters of particular interest in CMB polarization studies are: M_{II} , M_{QQ} , and M_{UU} , the diagonal elements of the Mueller matrix; M_{QI} and M_{UI} , the leakage of the total intensity signal into the (generally) small linear polarization signal; and M_{QU} and M_{UQ} , which measure the rotation of the linear polarization vector by the receiver.

8

$$M_{II} = \frac{L_{c}^{2} L_{omt}^{2}}{2} \left[|G_{L}|^{2} + |G_{R}|^{2} \right]$$

$$M_{QQ} = L_{c}^{2} |G_{L} G_{R}| \left[|D|^{2} \cos(\theta_{3}) + |d|^{2} \cos(\theta_{4}) \right]$$

$$M_{UU} = L_{c}^{2} |G_{L} G_{R}| \left[\cos(\theta_{c}) \{ |D|^{2} \cos(\theta_{3}) - |d|^{2} \cos(\theta_{4}) \} - \sin(\theta_{c}) |Dd| \{ \sin(\theta_{1}) + \sin(\theta_{2}) \} \right]$$

$$M_{QI} = L_{c}^{2} |G_{L} G_{R}| |Dd| \left[\cos(\theta_{2}) + \cos(\theta_{1}) \right]$$

$$M_{UI} = L_{c}^{2} |G_{L} G_{R}| |Dd| \left[\sin(\theta_{1}) - \sin(\theta_{2}) \right]$$

$$M_{QU} = L_{c}^{2} |G_{L} G_{R}| \left[Dd \right] \left[\sin(\theta_{1}) - \sin(\theta_{2}) \right]$$

$$M_{UQ} = -L_{c}^{2} |G_{L} G_{R}| \left[\cos(\theta_{c}) \{ |D|^{2} \sin(\theta_{3}) - |d|^{2} \sin(\theta_{4}) \} + \sin(\theta_{c}) |Dd| \{ \cos(\theta_{2}) - \cos(\theta_{1}) \} \right]$$

$$M_{UQ} = -L_{c}^{2} |G_{L} G_{R}| \left[|D|^{2} \sin(\theta_{3}) + |d|^{2} \sin(\theta_{4}) \right]$$
(19)
where $\theta_{1} = \theta_{Dy} - \theta_{dxy} - (\theta_{GL} - \theta_{GR} + \theta_{ps})$

$$\theta_{2} = \theta_{Dx} - \theta_{dyx} + (\theta_{GL} - \theta_{GR} + \theta_{ps})$$

$$\theta_{3} = \theta_{Dx} - \theta_{Dy} + (\theta_{GL} - \theta_{GR} + \theta_{ps})$$

$$\theta_3 = \theta_{D_x} - \theta_{D_y} + (\theta_{G_L} - \theta_{G_R} + \theta_{ps}) \theta_4 = \theta_{d_{xy}} - \theta_{d_{yx}} + (\theta_{G_L} - \theta_{G_R} + \theta_{ps})$$

Here $X = |X|e^{i\theta_X}$. We have implicitly assumed that the responses of all the power detectors are equal and stable.

To keep the comparison between the architectures reasonable, we need to include varying power detection sensitivity in the differencing polarimeter. Let the power detection proportionality constants (see Equation 13) be α_1 and α_2 for outputs 1 and 2 respectively. We also need to decide on the rotation angle of the Faraday rotator to specify which linear Stokes parameter we actually measure. Let $\theta_{ps} = \pm 45^{\circ}$ (i.e. Stokes U). We then obtain the Mueller matrix parameters:

$$M_{II} = \frac{L_{omt}^2}{2} \left[\alpha_1 + \alpha_2 \right]$$

$$M_{UU} = \frac{\sin(2\theta_{ps})}{2} \left[\alpha_1 + \alpha_2 \right] \left[|D|^2 - |d|^2 \right] - \cos(2\theta_{ps}) |Dd|$$

$$\left[\alpha_1 \cos(\theta_{D_x} - \theta_{d_{xy}}) - \alpha_2 \cos(\theta_{D_y} - \theta_{d_{yx}}) \right]$$

$$M_{UI} = \frac{L_{omt}^2}{2} \left[\alpha_1 - \alpha_2 \right]$$

$$M_{UQ} = \frac{\cos(2\theta_{ps})}{2} \left[\alpha_2 - \alpha_1 \right] \left[|D|^2 - |d|^2 \right] - \sin(2\theta_{ps}) |Dd|$$

$$\left[\alpha_1 \cos(\theta_{D_x} - \theta_{d_{xy}}) - \alpha_2 \cos(\theta_{D_y} - \theta_{d_{yx}}) \right]$$
(20)

1) Discussion: One of the greatest sources of systematic error in polarimeters is leakage of the total intensity signal into the measured linear polarization amplitude, $P = \sqrt{Q^2 + U^2}$. The fractional contribution to P from total intensity leakage, $\Delta P_I = M_{PI}/M_{II}$, is given by:

$$\Delta P_I = \frac{\sqrt{M_{QI}^2 + M_{UI}^2}}{M_{II}}$$

Assume that we have two differencing polarimeters oriented such that they measure Q and U respectively, identical except for their values of α . The "Q" polarimeter has values α_1, α_2 , while the "U" polarimeter has α_3, α_4 . For the pseudo-



Fig. 6. Comparison of the effect of imbalance on the fractional total intensity to polarization leakage for pseudo-correlation and differencing polarimeter architectures. For the pseudo-correlation architecture, $\Delta = \Delta |G|^2$. For the differencing architecture $\Delta = \Delta \alpha$. $|d|^2$ is the OMT cross polarization.

correlation and differencing polarimeters we then have:

$$\Delta P_I^c = \frac{2\sqrt{2}|G_L G_R|}{|G_L|^2 + |G_R|^2} |d| \sqrt{(1 - |d|^2)(1 + \cos(\theta_1 + \theta_2))}$$
$$\Delta P_I^d = 2\frac{\sqrt{(\alpha_1 - \alpha_2)^2 + (\alpha_3 - \alpha_4)^2}}{\alpha_1 + \alpha_2 + \alpha_3 + \alpha_4}$$

As a simplification, assume that $\Delta \alpha = (\alpha_1 - \alpha_2)/\alpha_2 = (\alpha_3 - \alpha_4)/\alpha_4$, and let $\Delta |G|^2 = \frac{|G_L|^2 - |G_R|^2}{|G_R|^2}$. Take the worst-case phase scenario, where $\cos(\theta_1 + \theta_2) = 1$. We now have:

$$\Delta P_I^c = 4|d|\sqrt{1-|d|^2}\frac{\sqrt{1+\Delta}|G|^2}{2+\Delta}|G|^2$$
(21)

$$\Delta P_I^d = \frac{\sqrt{2\Delta\alpha}}{2+\Delta\alpha} \tag{22}$$

Equations 21 and 22 are plotted in Figure 6. Several attributes are noteworthy: ΔP_I is *independent* of the OMT cross polarization $|d|^2$ for the differencing polarimeter, but is heavily dependent on the power sensitivity imbalance $\Delta \alpha$; ΔP_I is almost independent of gain imbalance $\Delta |G|^2$ for the pseudo-correlation polarimeter, but is dependent on the OMT cross polarization.

Figure 6 clearly illustrates the difference between the polarimeter architectures in terms of total intensity to polarization leakage. Correlation polarimeters are very insensitive to what is generally the most unstable parameter in a coherent receiver: fluctuating LNA gain. They are moderately sensitive to OMT cross polarization $|d|^2$. The comparatively high sensitivity of differencing polarimeters to power detection imbalance can be reduced if $\Delta \alpha$ is stable and well-known; the data can then be corrected and the leakage of *I* into *P* reduced.

E. Pseudo-Correlation Polarimeter Noise Temperature

A very powerful benefit of using scattering matrices to model receivers is the ability to perform noise analysis. We specify parameterized noise wave vectors for the pre-LNA components and ignore any noise produced by the components "down stream" of the LNAs, as their contribution will be negligible if the LNA gain is high.

If the noise wave vector of the pseudo-correlation polarimeter is given by c, then the noise power measured at the output D_i in a 1 Hz bandwidth is given by $P_i = \alpha \langle c_j c_j^* \rangle$, where c_j is the noise wave vector element corresponding to output D_i .

Suppose that component k of M total components has N ports, and is specified by the scattering matrix \mathbf{S}^k and the noise wave vector \mathbf{c}^k . c_j is given by:

$$c_j = \sum_{k=1}^{M} c_j^k$$
, where $c_j^k = \sum_{i=1}^{N} b_i^k c_i^k$

Noise waves from different devices are not correlated: $\langle c_i^k (c_j^m)^* \rangle = 0$ for $k \neq m$. So, P_i is given by:

$$\begin{split} P_{i} = & \alpha \sum_{k=1}^{M} P_{i}^{k} \\ \text{where } P_{i}^{k} = \sum \sum \left(\mathbf{C}^{k} \cdot \left(\mathbf{b}^{k} \otimes (\mathbf{b}^{k})^{\dagger} \right) \right) \end{split}$$

Here \mathbf{C}^k is the noise correlation matrix for component k, \cdot is the matrix dot product, \mathbf{b}^k is the vector $[b_1^k \dots b_N^k]^T$, \otimes is the outer product, and † is the hermitian conjugate. The $\sum \sum$ indicates a sum over all the matrix elements.

The noise correlation matrices for the passive pre-LNA components are obtained using Equation 2. To get the noise correlation matrices for the LNAs we make two simplifications to the HEMT noise correlation matrix model in [5]: first, the off-diagonal terms of an LNA noise correlation matrix $(\langle c_1 c_2^* \rangle$ and $\langle c_1^* c_2 \rangle)$ are much smaller than the diagonal terms so we take them to be zero. Second: $\langle |c_2|^2 \rangle \simeq |S_{21}|^2 \langle |c_1|^2 \rangle \simeq k |S_{21}|^2 T_N$, where T_N is the amplifier noise temperature and k is Boltzmann's constant.

Receiver noise temperature is referenced to the input. We consider the receiver temperature T_i at output D_i to be the temperature of a thermal source seen equally at each input which produces the same total output noise power in a noiseless receiver:

$$P_{i} = \alpha \Big(\sum_{j=1}^{N_{\text{in}}} |S_{ij}|^{2} \Big) T_{i}$$

$$\therefore T_{i} = \frac{\sum_{k=1}^{M} P_{i}^{k}}{\sum_{j=1}^{N_{\text{in}}} |S_{ij}|^{2}}$$
(23)

Here N_{in} is the number of inputs to the receiver, and S is the receiver scattering matrix.

Applying this technique to the pseudo-correlation polarimeter we derive the receiver temperatures for the outputs D_1 to



Fig. 7. Plots of T_1/T_N against various parameters. We see that the receiver is most sensitive to the cross polarization, $|d|^2$, and is negligibly sensitive to the other parameters. We assume $T_N = T_P = 15$ K. See text for details.

$$D_{4}:$$

$$T_{1} = T_{c} + \frac{T_{p}}{L_{c}^{2}} \Big[\frac{G}{E - F} - 1 \Big] + \frac{T_{N}}{L_{c}^{2}} \Big[\frac{G}{E - F} \Big]$$

$$T_{2} = T_{c} + \frac{T_{p}}{L_{c}^{2}} \Big[\frac{G}{E + F} - 1 \Big] + \frac{T_{N}}{L_{c}^{2}} \Big[\frac{G}{E + F} \Big]$$

$$T_{3} = T_{c} + \frac{T_{p}}{L_{c}^{2}} \Big[\frac{G}{E - H} - 1 \Big] + \frac{T_{N}}{L_{c}^{2}} \Big[\frac{G}{E - H} \Big]$$

$$T_{4} = T_{c} + \frac{T_{p}}{L_{c}^{2}} \Big[\frac{G}{E + H} - 1 \Big] + \frac{T_{N}}{L_{c}^{2}} \Big[\frac{G}{E + H} \Big] \quad (24)$$
where $T_{c} = T_{p} \Big[\frac{1}{L_{c}^{2}} - 1 \Big]$

$$G = |G_{L}|^{2} + |G_{R}^{2}|$$

$$E = (|G_{L}|^{2} + |G_{R}^{2}|)L_{omt}^{2}$$

$$F = 2|G_{L}G_{R}||Dd| \Big[\cos(\theta_{1}) + \cos(\theta_{2}) \Big]$$

$$H = 2|G_{L}G_{R}||Dd| \Big[\sin(\theta_{1}) - \sin(\theta_{2}) \Big]$$

Here we have assumed that the amplifiers have noise temperature T_N , and that the circularizer and OMT are at a physical temperature of T_p . θ_1 and θ_2 are given in Equation 19.

1) Discussion: Which parameters in the multiparameter expression for T_1 in Equation 24 have the greatest impact on the receiver temperature? The most obvious are L_c^2 and L_{omt}^2 , the insertion losses of the circularizer and OMT respectively. Setting those aside, how do the other parameters affect the receiver temperature?

The minimum value that T_1 can have is T_N . Our sensitivity impact metric is then $T_1/T_N \ge 1$. We fix $L_c^2 = -0.1$ dB and $L_{omt}^2 = -0.2$ dB, and set $|G_R| = 1$, $|G_L| = \sqrt{1 + \Delta |G|^2}$, $\theta_{G_L} = 0$, and $\theta_{D_x} = 0$ (only relative phases matter here). This leaves us with six parameters: $|d|^2$, $\Delta |G|^2$, θ_{G_R} , θ_{D_y} , $\theta_{d_{xy}}$, and $\theta_{d_{yx}}$.

We generate random sets of physically realistic values for these parameters, and evaluate the metric T_1/T_N for each set. We plot T_1/T_N against each parameter under consideration in Figure 7. It is immediately clear that the most important parameter in this set is $|d|^2$. Discarding the least important parameters we now have:

$$T_{1} \simeq \frac{1}{L_{c}^{2}} \frac{T_{p} + T_{N}}{L_{omt}^{2} - 2|d|\sqrt{L_{omt}^{2} - |d|^{2}}} - T_{p}$$
$$\simeq \frac{T_{p}(1 - L_{c}^{2}L_{omt}^{2}) + T_{N}}{L_{c}^{2}L_{omt}^{2}} \text{ since } |d|^{2} \ll L_{omt}^{2}$$
(25)

This simplified expression for T_1 is exactly what we would derive using a conventional noise temperature analysis, indicating that the software has calculated the noise temperature correctly.

VII. CONCLUSIONS

We have presented SNS, a MATLAB-based software library written to aid in the design and analysis of receiver architectures. It uses electrical scattering matrices and noise wave vectors to describe receiver architectures of arbitrary topology and complexity.

We use SNS to compare two polarimeter architectures commonly used to perform measurements of the polarized CMB: differencing polarimeters, an architecture commonly used in PSB-based polarimeters; and pseudo-correlation polarimeters, an architecture commonly used in coherent polarimeters. This analysis highlights the differing sources of systematic error in these architectures: I to P leakage in pseudo-correlation polarimeters is almost immune to gain imbalance, but sensitive to OMT cross polarization; while I to P leakage in differencing polarimeters is immune to OMT cross polarization, but very sensitive to power detection imbalance.

We show how SNS can be used to calculate analytical expressions for the receiver noise temperature of arbitrary receivers. Analytic expressions for the receiver temperature of a pseudo-correlation polarimeter are derived, and are found to be consistent with those obtained from conventional receiver temperature calculations.

ACKNOWLEDGMENTS

Thanks go to Dr Paul Grimes for helpful discussions and pointers to papers, to Prof. Mike Jones for helpful suggestions, support and motivation, and to Nikolai Yu. Zolotykh for developing the pointer library for MATLAB. OGK acknowledges the support of a Dorothy Hodgkin Award in funding his studies while a student at Oxford, and the support of a W.M. Keck Institute for Space Studies Postdoctoral Fellowship at Caltech.

REFERENCES

- M. Zaldarriaga and U. Seljak, "All-sky analysis of polarization in the microwave background", *Physical Review D (Particles*, vol. 55, p. 1830, Jan 1997.
- [2] L. Page, G. Hinshaw, E. Komatsu, M. R. Nolta, D. N. Spergel, C. L. Bennett, C. Barnes, R. Bean, O. Doré, J. Dunkley, M. Halpern, R. S. Hill, N. Jarosik, A. Kogut, M. Limon, S. S. Meyer, N. Odegard, H. V. Peiris, G. S. Tucker, L. Verde, J. L. Weiland, E. Wollack, and E. L. Wright, "Three-year Wilkinson Microwave Anisotropy Probe (WMAP) observations: Polarization analysis", *The Astrophysical Journal Supplement Series*, vol. 170, p. 335, May 2007.
- [3] W. Hu, M. M. Hedman, and M. Zaldarriaga, "Benchmark parameters for CMB polarization experiments", *Physical Review D*, vol. 67, p. 43004, Feb 2003.
- [4] D. O'Dea, A. Challinor, and B. R. Johnson, "Systematic errors in cosmic microwave background polarization measurements", *Monthly Notices of the Royal Astronomical Society*, vol. 376, p. 1767, Apr 2007.
- [5] S. Wedge and D. Rutledge, "Wave techniques for noise modeling and measurement", *Microwave Theory and Techniques, IEEE Transactions* on, vol. 40, no. 11, pp. 2004–2012, 1992.
- [6] —, "Noise waves and passive linear multiports", *Microwave and Guided Wave Letters, IEEE Transactions On*, vol. 1, no. 5, pp. 117–119, 1991.
- [7] G. Filipsson, "A new general computer algorithm for S-matrix calculation of interconnected multiports", 11th European Microwave Conference, pp. 700–704, 1981.
- [8] J. Ward, F. Rice, G. Chattopadhyay, and J. Zmuidzinas, "Supermix: a flexible software library for high-frequency circuit simulation, including SIS mixers and superconducting elements", *Tenth International Symposium on Space Terahertz Technology: Symposium Proceedings*, pp. 268–281, 1999.
- [9] J. P. Hamaker, J. D. Bregman, and R. J. Sault, "Understanding radio polarimetry. I. Mathematical foundations", *Astronomy and Astrophysics Supplement*, vol. 117, p. 137, May 1996.
- [10] W. C. Jones, T. E. Montroy, B. P. Crill, C. R. Contaldi, T. S. Kisner, A. E. Lange, C. J. Mactavish, C. B. Netterfield, and J. E. Ruhl, "Instrumental and analytic methods for bolometric polarimetry", *Astronomy* and Astrophysics, vol. 470, p. 771, Aug 2007.
- [11] L. Newburgh and QUIET Collaboration, "QUIET: The Q/U Imaging ExperimenT", American Astronomical Society, vol. 215, p. 549, Jan 2010.
- [12] J. Zmuidzinas, "Progress in coherent detection methods", *The Physics and Chemistry of the Interstellar Medium*, p. 423, Aug 1999.
- [13] T. C. Gaier, "Coherent radiometers for cosmic microwave background polarization detection", *Polarimetry in Astronomy. Edited by Silvano Fineschi . Proceedings of the SPIE*, vol. 4843, p. 296, Jan 2003.
- [14] B. G. Keating, "Faraday rotation modulators for mm-wavelength polarimetry", CMBPol White Papers, pp. 1–12, Jul 2008.